


OUTPOST CARRYALL™

Bag

Part# 7085457



TO MOUNT THE OUTPOST CARRYALL BAG:

STEP 1: Choose which side of your stem you'd like the Carryall bag mounted. Bag mounts on either side.


STEP 2: If necessary move the removable velcro strap to the correct side of the bag.

STEP 3: Loop the velcro straps to the handlebar and stem. Do not completely tighten. Loop the lower tension strap around the fork crown.

STEP 4: Position bag so it does not interfere with bike controls, then tighten the two velcro straps.

STEP 5: Pull lower tension strap snug and tie off any excess strapping so it does not fall into wheel.

Removable velcro strap around stem.
Bandoulière amovible.



▲ WARNING: ENSURE THAT THE BAG IS PROPERLY SECURED BEFORE EACH RIDE. MAKE SURE MOUNT DOES NOT INTERFERE WITH BIKE CONTROLS. DO NOT LEAVE VALUABLES UNATTENDED.

Visit us at blackburndesign.com for product updates.

Blackburn 

Customer Service: 1-800-456-2355

Blackburndesign.com

Printed in China

**LIFETIME
WARRANTY**